

Eclipse

Operation Instructions For Full Function Syncro



Back Tension Knob
Tighten - Turn Clockwise
Loosen - Turn Counter
Clockwise

Seat Height Lever
Lift to - Raise/Lower

Back Lock Knob
LOCK - Turn Forward
Unlock - Turn Back
and lean back until
there is a click to
release



Seat Slider Lever - Lift lever up and push forward. on the seat.
To return- Unweight the seat and the spring return it to original position

Eclipse

Operation Instructions For Fold Back Arm

